



Weighing Scale WS-130 and WS-100-EC

Introduction:

LCD - Indication	Description
→ 0 ←	Indicates that scale is ready "calibrated" for use
N	net weight indication
G	Gross weight indication
T	tare indication
lb, kg	weighing unit, normally on kg
bAtt	low-battery indication
▶ ◀	In level indication

Instructions of use:

- Press **ON** to start the scale
- Press **ZERO** if display-indication is not on 0.00
- Place refrigerant cylinder on platform
- Wait for indication to stabilize
- If the weight on the platform exceeds the max. weight of 130 kg, the display indicates "□□□□□□"
- Press **TARE** to put the scale to zero
- Fill the refrigeration unit until the requested weight, shows on the display



Features:

- Press **NET GROSS** to switch between gross and net weight (only possible if **TARE** has been previously set)
- Automatic switch off after 20 minutes stand by

Technical data:

Capacity max	130kg (WS-130), 100kg (WS-100-EC)
Resolution	10g (WS-130), 50g (WS-100-EC)
Accuracy	+/- 0,1%
Dimensions mm.	260 x 345 x 57
Power supply	2 pcs. LR6/AA batteries
Battery-lifetime	approx. 15 hours